

INSTALLATION INSTRUCTION

LED POOL LIGHT



TECHNICAL DATA

2 YEAR
WARRANTY*

Model No.	SKU	Watts	Beam Angle	Lumens	Input Voltage	Color Temp.	CRI	Dimension
VT-1258	7555	8W	120°	800LM	AC/DC 12V, 50/60Hz	6400K	Ra>80	178*114mm
	7556					3000K		
	7557					BLUE		
VT-1268	7558	8W	120°		AC 12V, 50/60Hz	RGB	Ra>80	178*114 mm
VT-1262	7559	12W	120°	1200LM	AC/DC 12V, 50/60Hz	6400K	Ra>80	178*114 mm
	7560					3000K		
	7561					Blue		
VT-1263	7562	12W	120°		AC12V, 50/60Hz	RGB	Ra>80	178*114 mm

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC Product. V-TAC will serve you the best. Please read these instructions carefully before starting the installing and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 2 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

WARNING!

1. Please make sure to turn off the power before starting the installation.
2. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
3. Install only by certified Electrician.




This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.

DIMENSIONS:




REMOTE FUNCTIONS:

Key1: It can be switch to R G B RG GB RB RGB ect Seven kinds of static model.

Key2: It can change to RGB clockwise jump mode, RGB anticlockwise jump mode. RGB full color jump mode, RGB gradualistic model one RGB gradualistic model two ect five kinds of dynamic change mode.

Key3: It can adjust the speed of dynamic change modes. There are 10 kinds speed grade.

Key4: Means turn or turn off the power



INSTALLATION DIAGRAM:

STEP 1

Take out the pool embedded parts, twist off the screws from the lid, and then take off the lid.




STEP 2

Connect the power output cable of the embedded parts with the terminals of the lamp, and then tighten the screws.



STEP 3

Put the lamp, into the embedded parts and cover the lid and tighten the screws.



In case of any query/issue with the product please reach out to us at support@vtacexports.com
V-TAC EUROPE LTD, Bulgaria, Plovdiv 4000, bul.L.Karavelov 9B