



OPERATION GUIDE

Operation Instruction of the lamp



PACKING LIST



Operation Cautions:

1. Please do not put the lamp on the high-temperature surfaces, and do not use it in flammable or humid environment, to avoid the breakdown, short circuit etc.
2. The adapter must be under the specialized range.
3. Please steady the base while adjusting the arm.
4. The lamp head can be adjusted freely under the adjustment range. But be cautious and never over adjustment to result in breakdown.

Maintenance

1. Please clear the lamp every two months to keep it smooth and bright.
2. Just use cleaning cloth and water to clean the dust.
3. For the filthy mark, please use cleaning cloth and soap suds.
4. Please do not clean the lamp by high-volatility and high-corrosive liquid which can make it discoloring or broken.



Power off before cleaning.
Please ask for the professional person for checking and repairing when it is broken.
If any abnormal cases, power off rapidly and contact dealer or manufacturer.



Send back this guarantee card to our Service Dept

GUARANTEE

User Name: _____ Tel: _____
Purchasing Date: _____
Item NO.: _____
Serial NO.: _____
Address: _____
Invoice NO.: _____
Purchasing Store: _____
Manufacture Date: _____

VTAC EUROPE LTD
Bulgaria, Plovdiv 4000,
bul. L. Karavelov 9B



V-TAC[®]
INNOVATIVE LED LIGHTING

Floor Lamp

User Manual



VT-7500

SKU: 7055 7056