5 Channel RGB+CCT LED RF Controller





5 Channels/Step-less dimming/Wireless remote control/Push Dim/Auto-transmitting/Synchronize



FC C CE RoHS emc RED

RF 2.4GHz + Push Dim

Features

- Match with Skydance's 2.4G RGB+CCT remote control.
- One RF controller accept up to 10 remote control.
- Built in 10 dynamic mode, include jump or gradual change style.
- Auto-transmitting function: Controller automaticly transmit signal to another controller with 30m control distance.
- Synchronize on multiple number of controllers.
- Connect with external push switch to achieve on/off and dimming function.

Technical Parameters

Input and Output		
Input voltage	12-24VDC	
Input current	25.5A	
Output voltage	5 x (12-24)VDC	
Output current	5CH,5A/CH	
Output power	5 x (60-120)W	
Output type	Constant voltage	

Dimming level	4096 levels
Dimming range	0-100%
Dimming curve	Logarithmic
PWM Frequency	500Hz
Environment	
Operation temperature	Ta:-30°C ~+55°C

30m

Tc:+85°C

IP20

Dimming data

Control distance

Case temperature (Max.)


IP rating


Input signal

Safety and EMC		
EMC standard (EMC)	EN301 489,EN 62479	
Safety standard(LVD)	EN60950	
Radio Equipment(RED)	EN300 328	
Certification	CE,EMC,LVD,RED	


Warranty and Protection		
Warranty	5 years	
Protection	Reverse Polarity	

Mechanical Structures and Installations





Wiring Diagram



Note: Long press match key for 10s, RGB and CCT light can not be on at the same time. Long press match key for 15s, RGB and CCT light can be on at the same time. above operation will also restore the factory setting.

Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:

Short press match key, immediately press on/off key (single zone remote) or zone key (multiple zone remote) of the remote.

Delete:

Press and hold match key for 5s to delete all match, The light blinks 5 times means all matched remotes were deleted.

Use Power Restart

Match:

Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The light blinks 3 times means match is successful.

Delete:

Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

Available remote controller



1 zone remote



4 zone remote



1 zone remote



4 zone remote



4 zone remote

Push Dim

Click	ON/OFF	
Double Click	Change from color mode to tunable white mode and vice-versa	
Long press(>1s) from OFF	If on color mode change rotation speed; If on tunable white mode color temperature UP/DOWN (turn off and turn on to return dimming)	
Long press(>1s) from ON	If on color mode start/stop color rotation; If on tunable white mode dimming UP/DOWN	

Color rotation:

We can select 4 rotation speed:

- 10 flash/s means 6 seconds color rotation
- 5 flash/s means 30 seconds color rotation
- 2 flash/s means 1 minute color rotation
- 1 flash/s means 6 minutes color rotation

Dynamic mode list


No.	Name	No.	Name
1	RGB jump	6	RGB fade in and out
2	RGB smooth	7	Red fade in and out
3	6 color jump	8	Green fade in and out
4	6 color smooth	9	Blue fade in and out
5	Color temperature smooth	10	White fade in and out


Dual color control

CH4=Warm white LED CH5=Cool white LED


Each channel can supply up to 120W(@24V) and white balance can be controlled as such:

Color temperature	Cool white	Neutral white	Warm white
Power distribution	CH4=0W,CH5=120W	CH4=120W,CH5=120W	CH4=120W,CH5=0W






Dimming curve for CCT



Dimming curve for RGB



Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	 No power. Wrong connection or insecure. 	 Check the power. Check the connection.
Wrong color	1. Wrong connection of R/G/B/WW/CW wires.	1. Reconnect R/G/B/WW/CW wires.
Uneven intensity between front and rear, with voltage drop	 Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. 	 Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater.
No response from the remote	 The battery has no power. Beyond controllable distance. The controller did not match the remote. 	 Replace battery. Reduce remote distance. Re-match the remote.